


## Art.3351 Telephone

**IMPORTANT NOTE:** The incoming call tone comes out of the telephone ear piece.

Do not hold the hook switch down while holding the telephone to your ear.



**Door release button:**  
Pressing this at any time will open the door.

**Camera Recall:** ●  
Pressing this will switch on the picture

**Spare service buttons:**  
● ● S1 S2

**Three position volume control:**  
Use this to adjust the incoming call volume.

Contrast Control

Brightness Control

### ANSWERING A CALL

**STEP 1**

An incoming call will be signalled by an audible tone from the handset and the picture will appear

**STEP 2**

Pick up the handset and speak with the caller

**STEP 3**

To open the door press the button. To end the call hang up